5. MAIN Electrical Parts List

SEC Code	Design LOC	Description
0403-001972	D501	DIODE-ZENER
0403-001972	ZD300	DIODE-ZENER
0404-001250	D500	DIODE-SCHOTTKY
0404-001669	D600	DIODE-SCHOTTKY
0406-001267	D300	DIODE-TVS
0406-001267	D301	DIODE-TVS
0406-001267	D302	DIODE-TVS
0406-001267	D303	DIODE-TVS
0406-001267	D304	DIODE-TVS
0406-001267	D310	DIODE-TVS
0406-001267	D311	DIODE-TVS
0406-001293	D200	DIODE-TVS
0406-001293	D201	DIODE-TVS
0406-001293	D202	DIODE-TVS
0406-001293	D203	DIODE-TVS
0406-001293	D208	DIODE-TVS
0406-001293	D502	DIODE-TVS
0406-001293	D503	DIODE-TVS
0406-001293	D601	DIODE-TVS
0406-001293	D700	DIODE-TVS
0406-001293	D701	DIODE-TVS
0406-001413	D204	DIODE-TVS
0406-001413	D206	DIODE-TVS
0406-001413	D207	DIODE-TVS
0406-001413	D306	DIODE-TVS
0406-001413	D307	DIODE-TVS
0406-001413	D308	DIODE-TVS
0406-001413	D309	DIODE-TVS
0504-001113	TR503	TR-DIGITAL
0505-002088	TR300	FET-SILICON
0505-002088	TR501	FET-SILICON
0505-002341	TR504	FET-SILICON
0505-002384	TR700	FET-SILICON
0505-002652	TR200	FET-SILICON
0505-002720	TR301	FET-SILICON
0505-002720	TR500	FET-SILICON

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

0801-003437	U203	IC-CMOS LOGIC
0902-003010	UCP400	IC-MICROPROCESSOR
1001-001846	U200	IC-ANALOG MULTIPLEX
1003-002469	U704	IC-LEVEL DRIVER
1009-001058	U707	IC-HALL EFFECT S/W
1107-002239	UME400	IC-FLASH MEMORY
1201-003579	U101	IC-GPS AMP
1202-001121	U202	IC-VOLTAGE COMP.
1203-002250	U503	IC-VOL. DETECTOR
1203-002999	U302	IC-VOL. DETECTOR
1203-004776	U504	IC-POSI.FIXED REG.
1203-004819	U201	IC-POSI.FIXED REG.
1203-004819	U601	IC-POSI.FIXED REG.
1203-006872	U703	IC-MULTI REG.
1203-007321	U502	IC-POWER SUPERVISOR
1203-007332	U500	IC-POWER SUPERVISOR
1203-007623	U501	IC-BATTERY
1203-007624	U602	IC-BACKLIGHT DRIVER
1203-007795	U300	IC-VOL. DETECTOR
1203-007823	U600	IC-DC/DC CONVERTER
1204-003387	U700	IC-REMOTE CONTROL
1205-004233	U702	IC-TRANSMITTER
1205-004598	U104	IC-WIFI
1205-004649	U102	IC-GPS RECEIVER
1205-004719	U400	IC-SWITCH
1205-004804	U204	IC-CODEC
1205-004850	U701	IC-COMM. CONTROLLER
1209-002142	U705	IC-SENSOR
1209-002153	U706	IC-SENSOR
1404-001749	VR400	THERMISTOR-NTC
1404-001749	VR401	THERMISTOR-NTC
2007-000140	R453	R-CHIP
2007-000140	R454	R-CHIP
2007-000143	R711	R-CHIP
2007-000143	R712	R-CHIP
2007-000148	R740	R-CHIP
2007-000148	R741	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2007-000162	R506	R-CHIP
2007-003015	R307	R-CHIP
2007-003015	R308	R-CHIP
2007-007131	R607	R-CHIP
2007-007136	R473	R-CHIP
2007-007312	R482	R-CHIP
2007-007312	R483	R-CHIP
2007-007316	R737	R-CHIP
2007-007316	R738	R-CHIP
2007-007317	R204	R-CHIP
2007-007318	R487	R-CHIP
2007-007517	R442	R-CHIP
2007-007517	R443	R-CHIP
2007-007517	R480	R-CHIP
2007-007517	R481	R-CHIP
2007-007573	R216	R-CHIP
2007-007741	R219	R-CHIP
2007-007741	R447	R-CHIP
2007-007741	R457	R-CHIP
2007-007741	R507	R-CHIP
2007-007741	R716	R-CHIP
2007-007741	R719	R-CHIP
2007-007942	R203	R-CHIP
2007-007942	R217	R-CHIP
2007-007942	R432	R-CHIP
2007-008045	R514	R-CHIP
2007-008048	R720	R-CHIP
2007-008048	R721	R-CHIP
2007-008052	R425	R-CHIP
2007-008052	R426	R-CHIP
2007-008052	R427	R-CHIP
2007-008052	R428	R-CHIP
2007-008052	R455	R-CHIP
2007-008052	R456	R-CHIP
2007-008052	R478	R-CHIP
2007-008052	R508	R-CHIP
2007-008052	R701	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2007-008052	R702	R-CHIP
2007-008052	R706	R-CHIP
2007-008052	R707	R-CHIP
2007-008052	R709	R-CHIP
2007-008052	R714	R-CHIP
2007-008055	R314	R-CHIP
2007-008055	R419	R-CHIP
2007-008055	R422	R-CHIP
2007-008055	R458	R-CHIP
2007-008055	R461	R-CHIP
2007-008055	R462	R-CHIP
2007-008055	R463	R-CHIP
2007-008055	R466	R-CHIP
2007-008055	R472	R-CHIP
2007-008055	R474	R-CHIP
2007-008055	R475	R-CHIP
2007-008055	R476	R-CHIP
2007-008055	R477	R-CHIP
2007-008055	R505	R-CHIP
2007-008055	R516	R-CHIP
2007-008055	R605	R-CHIP
2007-008211	R306	R-CHIP
2007-008263	R488	R-CHIP
2007-008401	R208	R-CHIP
2007-008419	R515	R-CHIP
2007-008420	R300	R-CHIP
2007-008478	R436	R-CHIP
2007-008478	R437	R-CHIP
2007-008478	R449	R-CHIP
2007-008478	R450	R-CHIP
2007-008483	R301	R-CHIP
2007-008483	R302	R-CHIP
2007-008483	R304	R-CHIP
2007-008483	R305	R-CHIP
2007-008486	R502	R-CHIP
2007-008486	R509	R-CHIP
2007-008516	R100	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2007-008516	R101	R-CHIP
2007-008516	R102	R-CHIP
2007-008516	R126	R-CHIP
2007-008516	R303	R-CHIP
2007-008516	R310	R-CHIP
2007-008516	R402	R-CHIP
2007-008516	R420	R-CHIP
2007-008516	R468	R-CHIP
2007-008516	R469	R-CHIP
2007-008516	R470	R-CHIP
2007-008516	R471	R-CHIP
2007-008516	R479	R-CHIP
2007-008516	R710	R-CHIP
2007-008516	R715	R-CHIP
2007-008672	R722	R-CHIP
2007-008672	R723	R-CHIP
2007-008672	R724	R-CHIP
2007-008672	R725	R-CHIP
2007-008672	R726	R-CHIP
2007-008672	R727	R-CHIP
2007-008672	R728	R-CHIP
2007-008672	R729	R-CHIP
2007-008672	R730	R-CHIP
2007-008672	R731	R-CHIP
2007-008774	R312	R-CHIP
2007-008776	R700	R-CHIP
2007-008798	R501	R-CHIP
2007-008800	R440	R-CHIP
2007-008800	R441	R-CHIP
2007-008806	R200	R-CHIP
2007-008806	R205	R-CHIP
2007-008806	R207	R-CHIP
2007-008806	R735	R-CHIP
2007-008806	R736	R-CHIP
2007-009084	R209	R-CHIP
2007-009084	R218	R-CHIP
2007-009084	R315	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2007-009084	R433	R-CHIP
2007-009084	R448	R-CHIP
2007-009084	R489	R-CHIP
2007-009084	R503	R-CHIP
2007-009084	R504	R-CHIP
2007-009084	R513	R-CHIP
2007-009084	R705	R-CHIP
2007-009084	R734	R-CHIP
2007-009111	R412	R-CHIP
2007-009155	R111	R-CHIP
2007-009155	R127	R-CHIP
2007-009155	R500	R-CHIP
2007-009157	R413	R-CHIP
2007-009157	R414	R-CHIP
2007-009157	R416	R-CHIP
2007-009157	R417	R-CHIP
2007-009157	R418	R-CHIP
2007-009157	R446	R-CHIP
2007-009158	R717	R-CHIP
2007-009158	R718	R-CHIP
2007-009171	R112	R-CHIP
2007-009171	R113	R-CHIP
2007-009171	R114	R-CHIP
2007-009171	R115	R-CHIP
2007-009171	R116	R-CHIP
2007-009171	R400	R-CHIP
2007-009171	R403	R-CHIP
2007-009171	R404	R-CHIP
2007-009171	R405	R-CHIP
2007-009171	R406	R-CHIP
2007-009171	R407	R-CHIP
2007-009171	R408	R-CHIP
2007-009171	R409	R-CHIP
2007-009171	R410	R-CHIP
2007-009208	R201	R-CHIP
2007-009208	R202	R-CHIP
2007-009408	R430	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2007-009408	R431	R-CHIP
2007-009408	R434	R-CHIP
2007-009408	R435	R-CHIP
2007-009408	R444	R-CHIP
2007-009408	R445	R-CHIP
2007-009408	R451	R-CHIP
2007-009408	R452	R-CHIP
2007-009408	R600	R-CHIP
2007-009408	R601	R-CHIP
2007-009409	R606	R-CHIP
2007-009964	R467	R-CHIP
2007-010856	R517	R-CHIP
2007-010907	R120	R-CHIP
2203-000233	C115	C-CER,CHIP
2203-000254	C114	C-CER,CHIP
2203-000386	C725	C-CER,CHIP
2203-000386	C726	C-CER,CHIP
2203-000386	C727	C-CER,CHIP
2203-000489	C456	C-CER,CHIP
2203-000714	C457	C-CER,CHIP
2203-000714	C458	C-CER,CHIP
2203-000854	C618	C-CER,CHIP
2203-001101	C309	C-CER,CHIP
2203-001239	C303	C-CER,CHIP
2203-002687	C576	C-CER,CHIP
2203-002687	C577	C-CER,CHIP
2203-005249	C302	C-CER,CHIP
2203-005481	C716	C-CER,CHIP
2203-005682	C124	C-CER,CHIP
2203-005717	C513	C-CER,CHIP
2203-005717	C515	C-CER,CHIP
2203-005725	C107	C-CER,CHIP
2203-005725	C108	C-CER,CHIP
2203-005725	C150	C-CER,CHIP
2203-005727	C151	C-CER,CHIP
2203-005727	C583	C-CER,CHIP
2203-005727	C584	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-005727	C715	C-CER,CHIP
2203-005727	C717	C-CER,CHIP
2203-005729	C301	C-CER,CHIP
2203-005731	C453	C-CER,CHIP
2203-005731	C454	C-CER,CHIP
2203-005734	C307	C-CER,CHIP
2203-005736	C118	C-CER,CHIP
2203-005736	C120	C-CER,CHIP
2203-005736	C136	C-CER,CHIP
2203-005777	C116	C-CER,CHIP
2203-005777	C126	C-CER,CHIP
2203-005806	C113	C-CER,CHIP
2203-005806	C142	C-CER,CHIP
2203-006048	C459	C-CER,CHIP
2203-006048	C730	C-CER,CHIP
2203-006121	C722	C-CER,CHIP
2203-006194	C735	C-CER,CHIP
2203-006305	C119	C-CER,CHIP
2203-006305	C129	C-CER,CHIP
2203-006305	C138	C-CER,CHIP
2203-006305	C153	C-CER,CHIP
2203-006305	C154	C-CER,CHIP
2203-006305	C157	C-CER,CHIP
2203-006305	C160	C-CER,CHIP
2203-006305	C162	C-CER,CHIP
2203-006305	C163	C-CER,CHIP
2203-006305	C164	C-CER,CHIP
2203-006348	C304	C-CER,CHIP
2203-006348	C308	C-CER,CHIP
2203-006399	C202	C-CER,CHIP
2203-006399	C213	C-CER,CHIP
2203-006399	C231	C-CER,CHIP
2203-006399	C404	C-CER,CHIP
2203-006399	C407	C-CER,CHIP
2203-006399	C411	C-CER,CHIP
2203-006399	C412	C-CER,CHIP
2203-006399	C419	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-006399	C420	C-CER,CHIP
2203-006399	C421	C-CER,CHIP
2203-006399	C423	C-CER,CHIP
2203-006399	C424	C-CER,CHIP
2203-006399	C429	C-CER,CHIP
2203-006399	C430	C-CER,CHIP
2203-006399	C433	C-CER,CHIP
2203-006399	C434	C-CER,CHIP
2203-006399	C438	C-CER,CHIP
2203-006399	C439	C-CER,CHIP
2203-006399	C441	C-CER,CHIP
2203-006399	C442	C-CER,CHIP
2203-006399	C447	C-CER,CHIP
2203-006399	C511	C-CER,CHIP
2203-006399	C532	C-CER,CHIP
2203-006399	C535	C-CER,CHIP
2203-006399	C536	C-CER,CHIP
2203-006399	C537	C-CER,CHIP
2203-006399	C538	C-CER,CHIP
2203-006399	C550	C-CER,CHIP
2203-006399	C552	C-CER,CHIP
2203-006399	C605	C-CER,CHIP
2203-006399	C606	C-CER,CHIP
2203-006399	C621	C-CER,CHIP
2203-006399	C622	C-CER,CHIP
2203-006399	C701	C-CER,CHIP
2203-006399	C703	C-CER,CHIP
2203-006423	C112	C-CER,CHIP
2203-006423	C128	C-CER,CHIP
2203-006423	C145	C-CER,CHIP
2203-006423	C167	C-CER,CHIP
2203-006423	C400	C-CER,CHIP
2203-006423	C402	C-CER,CHIP
2203-006423	C405	C-CER,CHIP
2203-006423	C409	C-CER,CHIP
2203-006423	C415	C-CER,CHIP
2203-006423	C425	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-006423	C445	C-CER,CHIP
2203-006423	C446	C-CER,CHIP
2203-006423	C448	C-CER,CHIP
2203-006423	C455	C-CER,CHIP
2203-006423	C501	C-CER,CHIP
2203-006423	C512	C-CER,CHIP
2203-006423	C570	C-CER,CHIP
2203-006423	C578	C-CER,CHIP
2203-006423	C582	C-CER,CHIP
2203-006423	C590	C-CER,CHIP
2203-006423	C705	C-CER,CHIP
2203-006423	C707	C-CER,CHIP
2203-006423	C708	C-CER,CHIP
2203-006423	C710	C-CER,CHIP
2203-006423	C712	C-CER,CHIP
2203-006423	C714	C-CER,CHIP
2203-006423	C718	C-CER,CHIP
2203-006423	C723	C-CER,CHIP
2203-006423	C724	C-CER,CHIP
2203-006423	C729	C-CER,CHIP
2203-006423	C734	C-CER,CHIP
2203-006562	C201	C-CER,CHIP
2203-006562	C204	C-CER,CHIP
2203-006562	C215	C-CER,CHIP
2203-006562	C568	C-CER,CHIP
2203-006562	C579	C-CER,CHIP
2203-006562	C580	C-CER,CHIP
2203-006562	C588	C-CER,CHIP
2203-006562	C589	C-CER,CHIP
2203-006642	C147	C-CER,CHIP
2203-006642	C156	C-CER,CHIP
2203-006642	C416	C-CER,CHIP
2203-006642	C418	C-CER,CHIP
2203-006642	C422	C-CER,CHIP
2203-006668	C721	C-CER,CHIP
2203-006707	C132	C-CER,CHIP
2203-006707	C146	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-006707	C148	C-CER,CHIP
2203-006712	C736	C-CER,CHIP
2203-006824	C306	C-CER,CHIP
2203-006839	C140	C-CER,CHIP
2203-006839	C158	C-CER,CHIP
2203-006839	C206	C-CER,CHIP
2203-006839	C565	C-CER,CHIP
2203-006839	C566	C-CER,CHIP
2203-006839	C608	C-CER,CHIP
2203-006841	C585	C-CER,CHIP
2203-006872	C109	C-CER,CHIP
2203-006872	C208	C-CER,CHIP
2203-006872	C209	C-CER,CHIP
2203-006872	C210	C-CER,CHIP
2203-006872	C218	C-CER,CHIP
2203-006872	C221	C-CER,CHIP
2203-006872	C224	C-CER,CHIP
2203-006872	C225	C-CER,CHIP
2203-006872	C226	C-CER,CHIP
2203-006872	C401	C-CER,CHIP
2203-006872	C408	C-CER,CHIP
2203-006872	C414	C-CER,CHIP
2203-006872	C431	C-CER,CHIP
2203-006872	C435	C-CER,CHIP
2203-006872	C443	C-CER,CHIP
2203-006872	C444	C-CER,CHIP
2203-006872	C449	C-CER,CHIP
2203-006872	C533	C-CER,CHIP
2203-006872	C534	C-CER,CHIP
2203-006872	C539	C-CER,CHIP
2203-006872	C540	C-CER,CHIP
2203-006872	C548	C-CER,CHIP
2203-006872	C553	C-CER,CHIP
2203-006872	C554	C-CER,CHIP
2203-006872	C555	C-CER,CHIP
2203-006872	C556	C-CER,CHIP
2203-006872	C704	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-006872	C706	C-CER,CHIP
2203-006872	C709	C-CER,CHIP
2203-006872	C711	C-CER,CHIP
2203-006872	C713	C-CER,CHIP
2203-006979	C575	C-CER,CHIP
2203-006979	C586	C-CER,CHIP
2203-007210	C135	C-CER,CHIP
2203-007210	C155	C-CER,CHIP
2203-007210	C514	C-CER,CHIP
2203-007240	C500	C-CER,CHIP
2203-007240	C522	C-CER,CHIP
2203-007240	C523	C-CER,CHIP
2203-007240	C525	C-CER,CHIP
2203-007240	C526	C-CER,CHIP
2203-007270	C569	C-CER,CHIP
2203-007270	C610	C-CER,CHIP
2203-007270	C617	C-CER,CHIP
2203-007270	C740	C-CER,CHIP
2203-007271	C137	C-CER,CHIP
2203-007271	C311	C-CER,CHIP
2203-007271	C573	C-CER,CHIP
2203-007317	C144	C-CER,CHIP
2203-007317	C305	C-CER,CHIP
2203-007317	C403	C-CER,CHIP
2203-007317	C406	C-CER,CHIP
2203-007317	C410	C-CER,CHIP
2203-007317	C426	C-CER,CHIP
2203-007317	C427	C-CER,CHIP
2203-007317	C440	C-CER,CHIP
2203-007317	C502	C-CER,CHIP
2203-007317	C506	C-CER,CHIP
2203-007317	C507	C-CER,CHIP
2203-007317	C508	C-CER,CHIP
2203-007317	C509	C-CER,CHIP
2203-007317	C510	C-CER,CHIP
2203-007317	C516	C-CER,CHIP
2203-007317	C517	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-007317	C519	C-CER,CHIP
2203-007317	C720	C-CER,CHIP
2203-007317	C728	C-CER,CHIP
2203-007385	C428	C-CER,CHIP
2203-007385	C432	C-CER,CHIP
2203-007385	C436	C-CER,CHIP
2203-007385	C437	C-CER,CHIP
2203-007385	C732	C-CER,CHIP
2203-007385	C739	C-CER,CHIP
2203-007391	C560	C-CER,CHIP
2203-007393	C141	C-CER,CHIP
2203-007393	C143	C-CER,CHIP
2203-007393	C159	C-CER,CHIP
2203-007393	C161	C-CER,CHIP
2203-007393	C562	C-CER,CHIP
2203-007393	C615	C-CER,CHIP
2203-007393	C719	C-CER,CHIP
2203-007449	C105	C-CER,CHIP
2203-007449	C106	C-CER,CHIP
2203-007449	C110	C-CER,CHIP
2203-007449	C111	C-CER,CHIP
2203-007449	C130	C-CER,CHIP
2203-007449	C131	C-CER,CHIP
2203-007449	C200	C-CER,CHIP
2203-007449	C207	C-CER,CHIP
2203-007449	C211	C-CER,CHIP
2203-007449	C217	C-CER,CHIP
2203-007449	C219	C-CER,CHIP
2203-007449	C220	C-CER,CHIP
2203-007449	C413	C-CER,CHIP
2203-007449	C417	C-CER,CHIP
2203-007449	C541	C-CER,CHIP
2203-007449	C542	C-CER,CHIP
2203-007449	C543	C-CER,CHIP
2203-007449	C544	C-CER,CHIP
2203-007449	C545	C-CER,CHIP
2203-007449	C546	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-007449	C547	C-CER,CHIP
2203-007449	C549	C-CER,CHIP
2203-007449	C551	C-CER,CHIP
2203-007449	C557	C-CER,CHIP
2203-007449	C558	C-CER,CHIP
2203-007449	C559	C-CER,CHIP
2203-007449	C581	C-CER,CHIP
2203-007449	C601	C-CER,CHIP
2203-007449	C602	C-CER,CHIP
2203-007449	C612	C-CER,CHIP
2203-007449	C613	C-CER,CHIP
2203-007449	C614	C-CER,CHIP
2203-007449	C616	C-CER,CHIP
2203-007449	C700	C-CER,CHIP
2203-007449	C702	C-CER,CHIP
2203-007474	C503	C-CER,CHIP
2203-007474	C504	C-CER,CHIP
2203-007474	C505	C-CER,CHIP
2203-007474	C518	C-CER,CHIP
2203-007474	C520	C-CER,CHIP
2203-007474	C521	C-CER,CHIP
2203-007474	C524	C-CER,CHIP
2203-007474	C527	C-CER,CHIP
2203-007474	C528	C-CER,CHIP
2203-007474	C529	C-CER,CHIP
2203-007474	C530	C-CER,CHIP
2203-007474	C531	C-CER,CHIP
2203-007474	C611	C-CER,CHIP
2203-007474	C731	C-CER,CHIP
2203-007474	C733	C-CER,CHIP
2203-007775	C205	C-CER,CHIP
2203-007775	C620	C-CER,CHIP
2203-007781	C567	C-CER,CHIP
2203-007781	C572	C-CER,CHIP
2203-007781	C574	C-CER,CHIP
2203-007790	C603	C-CER,CHIP
2203-007790	C619	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2203-007795	C563	C-CER,CHIP
2203-007795	C564	C-CER,CHIP
2203-007796	C103	C-CER,CHIP
2203-007796	C134	C-CER,CHIP
2203-007796	C222	C-CER,CHIP
2203-007796	C223	C-CER,CHIP
2203-007796	C450	C-CER,CHIP
2203-007796	C451	C-CER,CHIP
2203-007796	C561	C-CER,CHIP
2203-007796	C571	C-CER,CHIP
2203-008095	C133	C-CER,CHIP
2703-002200	L110	INDUCTOR-SMD
2703-002204	L106	INDUCTOR-SMD
2703-002313	L300	INDUCTOR-SMD
2703-002365	L108	INDUCTOR-SMD
2703-002369	L107	INDUCTOR-SMD
2703-003687	L500	INDUCTOR-SMD
2703-003687	L507	INDUCTOR-SMD
2703-003687	L508	INDUCTOR-SMD
2703-003687	L509	INDUCTOR-SMD
2703-003687	L510	INDUCTOR-SMD
2703-004231	L600	INDUCTOR-SMD
2703-004289	L103	INDUCTOR-SMD
2703-004295	L102	INDUCTOR-SMD
2703-004297	L501	INDUCTOR-SMD
2703-004297	L502	INDUCTOR-SMD
2703-004297	L503	INDUCTOR-SMD
2703-004297	L504	INDUCTOR-SMD
2703-004297	L505	INDUCTOR-SMD
2703-004297	L506	INDUCTOR-SMD
2703-004297	L511	INDUCTOR-SMD
2703-004301	L115	INDUCTOR-SMD
2703-004302	L114	INDUCTOR-SMD
2703-004338	L113	INDUCTOR-SMD
2703-004366	L104	INDUCTOR-SMD
2703-004671	L601	INDUCTOR-SMD
2801-004785	OSC700	CRYSTAL-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

2801-005157	OSC500	CRYSTAL-SMD
2801-005163	OSC400	CRYSTAL-SMD
2801-005167	OSC101	CRYSTAL-SMD
2805-001098	OSC100	OSCILLATOR-TCXO
2901-001625	F600	FILTER-EMI/ESD
2901-001625	F601	FILTER-EMI/ESD
2901-001732	F602	FILTER-EMI SMD
2901-001732	F603	FILTER-EMI SMD
2901-001732	F604	FILTER-EMI SMD
2901-001732	F605	FILTER-EMI SMD
2904-001988	F100	FILTER-GPS SAW
2904-001988	F101	FILTER-GPS SAW
2909-001324	F103	FILTER-LC
2911-000257	U103	DUPLEXER-FEM
2911-000258	U105	DUPLEXER-FEM
3301-001729	L700	BEAD-SMD
3301-001729	L701	BEAD-SMD
3301-001778	L111	CORE-FERRITE BEAD
3301-001895	L100	BEAD-SMD
3301-001895	L101	BEAD-SMD
3301-001929	L200	BEAD-SMD
3301-002179	L702	BEAD-SMD
3708-002222	HDC600	CONNECTOR-FPC/FFC/PIC
3709-001811	SOC300	CONNECTOR-CARD EDGE
3711-006141	HDC301	HEADER-BOARD TO BOARD
3711-006925	HDC602	HEADER-BOARD TO BOARD
3711-007172	HDC200	HEADER-BOARD TO BOARD
3711-007172	HDC201	HEADER-BOARD TO BOARD
3711-007173	HDC203	HEADER-BOARD TO BOARD
3711-007173	HDC400	HEADER-BOARD TO BOARD
3711-007295	HDC601	HEADER-BOARD TO BOARD
3711-007738	HDC202	HEADER-BOARD TO BOARD
3711-008151	HDC701	HEADER-BOARD TO BOARD
3711-008163	HDC700	HEADER-BOARD TO BOARD
3711-008347	HDC300	HEADER-BOARD TO BOARD
3711-008421	BTC500	CONNECTOR-HEADER
3712-001473	ANT100	CONNECTOR-TERMINAL

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

3712-001473	ANT101	CONNECTOR-TERMINAL
4709-001672	F104	FREQ-DISTRIBUTER
4709-002028	F102	FREQ-DISTRIBUTER
GH61-03724A	CN300	PLATE-ICT PCB
GH80-03321A	R108	SOLDER-CREAM/DHDMR(FREE)
GH80-03321A	R109	SOLDER-CREAM/DHDMR(FREE)
GH80-03321A	R117	SOLDER-CREAM/DHDMR(FREE)
GH80-03321A	R119	SOLDER-CREAM/DHDMR(FREE)
GH80-03321A	R122	SOLDER-CREAM/DHDMR(FREE)
GH80-03321A	R311	SOLDER-CREAM/DHDMR(FREE)
GH80-03321A	R313	SOLDER-CREAM/DHDMR(FREE)
GH80-03321A	R519	SOLDER-CREAM/DHDMR(FREE)
GH80-03321A	R739	SOLDER-CREAM/DHDMR(FREE)
GH98-27176A	SC101	ASSY COVER-SMD SHIELD CAN 1
GH98-27177A	SC100	ASSY COVER-SMD SHIELD CAN 2
GH98-27178A	SC600	ASSY COVER-SMD SHIELD CAN 3

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.

Confidential and proprietary-the contents in this service guide subject to change without prior notice.
Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.